

134K-RW-USB-D1

134.2Khz ISO11784/11785 RFID reader/writer with USB Writer Program User Guide

USB driver installation

Remarks :

Don't connect the USB reader with the PC when running below auto USB driver setup

[1] insert the USB driver disk to CD-ROM :

run the auto setup program from the following path :

cd-rom drive : \USB To Virtual Com driver\CP210x_VCP_Win2K_XP_S2K3.exe

windows OS support : 2000 , XP , Vista & 2003 server




[2] After driver installation → connect the USB reader to the PC's USB port with a USB cable .

Then the PC will find the reader and install the "USB to UART Bridge" driver automatically.

[3] After installation successfully , you will find "CP210xUSB to UART Bridge Controller (Com3)" as follow message from the control panel/system/hardware/device manager/port(COM & LPT) .

(may be see other COM port #, not the COM3 which is depend on your PC's hardware configuration)



134K-RW-USB Demo Program - user guide

Setup connection

- [1] Make sure the USB driver installation successfully
 - [2] copy full directory from the CD path : \demo program to your local PC
 - [3] run the demo program from the path : \demo program\EM4305 Demo.exe
 - [4] select a suitable "Com Port" No.
- If fails , Pls check or re-install the "USB to Serial" driver again.

EM4305 DEMO

Communication Port
Port: COM3

Read EM ID
Customer Code:
Data Item:
Read EM4001 Write EM4001

Protection
 Manchester RF/64 Bi-phase RF/32
Address: 1
Data: 51190816
Read Write

Configuration Word
Encoder + Data Rate:
 Manchester RF/64 Bi-phase RF/32
LWR:
LWR:
Configuration Switches:
 Read Login Disable
 Write Login Reader Talk First
 Pigeon mode
Write

Read Animal ID
Animal Data
National: 0211D36EFG
Country: 009C
CRC: B874
Trailer:
Read Write

Login PassWord
Password: Login
New PassWord: Write


Read/Write EEPROM
 Word 0 Word 1 Word 2 Word 3
 Word 4 Word 5 Word 6 Word 7
 Word 8 Word 9 Word A Word B
 Word C Word D Word E
Read Protection Bits Set Protection Bits

Others
Disable Card
Field ON Field OFF

How to read/write ISO11784/11785 data format

- [1] put the EM4205/EM4305 ear tag on the reader
- [2] enter ISO11784/11785 data , then click on "write"
- [3] Click on "Read" to read data

How to read and write internal memory data



- [1] click on "Bi-phase RF/32"
- [2] put the EM4205/EM4305 tag on the reader
- [3] Refer to below memory map , input the memory address and data
- [4] click on "Write " to write the data to the specify memory address
- [5] click on "Read" to read the data from the specify memory address

Below is the memory Map

Addr. (dec)	Description	Type	B ₀ , .., b ₃₁
0	Chip Type, Res Cap Customer code/ User free	RW	ct ₀ - Ct ₃₁
1	UID number	RA	uid ₀ - uid ₃₁
2	Password	WO	ps ₀ - ps ₃₁
3	User free	RW	us ₀ - us ₃₁
4	Configuration word	RW	co ₀ - co ₃₁
5	User free	RW	us ₀ - us ₃₁
6	User free	RW	us ₀ - us ₃₁
7	User free	RW	us ₀ - us ₃₁
8	User free	RW	us ₀ - us ₃₁
9	User free	RW	us ₀ - us ₃₁
10	User free	RW	us ₀ - us ₃₁
11	User free	RW	us ₀ - us ₃₁
12	User free	RW	us ₀ - us ₃₁
13	User free	RW	us ₀ - us ₃₁
14	Protection word 1	RP	pr ₀ - pr ₃₁
15	Protection word 2	RP	pr ₀ - pr ₃₁


Table 5

Word types:
 RA: access using Read Word command only
 RW: access using Read Word and Write Word command
 WO: access using Write Word command only
 RP: access using Read Word and Protect command

How to login by password

Default password is 00000000.

Input "New Password" then click on "Write" to change the password



Login Password

Password

New Password

How to set the protection bits

Tick to select which word is needed for protection

click on "Set protection Bits" to save

click on "Read protection Bits" to read the protection bit status



Read/Write EEPROM

Word 0 Word 1 Word 2 Word 3


Word 4 Word 5 Word 6 Word 7

Word 8 Word 9 Word A Word B

Word C Word D Word E

How to set configuration word

Refer to EM4205 / EM4305 datasheet in detail operation



Configuration Word

Encoder + Data Rate

Manchester RF/64 Bi-phase RF/32

LWR

LWR

Configuration Switches

Read Login Disable

Write Login Reader Talk First

Pigeon mode